SAUTER CATALOGUE 2021

Mobile Leeb hardness tester SAUTER HK-D \cdot HK-DB



Premium Leeb hardness tester – now also with hardness comparison block included

Features

- External impact sensor standard (Type D)
- Mobility: In comparison with stationary table-top devices and testing devices with an internal sensor, using the SAUTER HK-D. offers the highest level of mobility and flexibility
- All measurement directions possible (360°) thanks to an automatic compensation function
- SAUTER HK-DB.: Hardness comparison block, hardness approx. 800 HLD, included in delivery
- Delivered in a sturdy carrying case
- Measurement value display: Rockwell (Type A, B, C), Vickers (HV), Shore (HS), Leeb (HL), Brinell (HB)
- Internal memory for up to 600 data groups, with up to 32 values per group forming the average value of the group
- Mini statistics function: displays the measured result, the average value, the impact direction, date and time
- Automatic unit conversion: The measuring result is automatically converted into all specified hardness units

- Measuring with tolerance range (limit-setting function): Upper and lower limiting can be programmed individually. The process is supported by an audible and visual signal.
- Matrix display: Backlit multi-function display for all relevant functions at a glance
- Robust metal housing

Technical data

- Measuring precision: ± 1 % at 800 HLD
- Minimum sample radius (concave/convex):
 50 mm (with support ring: 10 mm)
- Minimum sample material thickness: 3 mm with coupling on fixed base
- The lowest weight of the test item on solid support unit: 2 kg with fixed coupling
- Dimensions W×D×H 132×82×31 mm
- Permissible ambient temperature -10 $^\circ\text{C}/40$ $^\circ\text{C}$
- Battery operation, batteries not standard 2× 1.5 V AA, operating time up to 200 h
- Net weight approx. 0,45 kg

SO





Accessories

- Plug-In for data transfer of measuring data from the measuring instrument and transfer to a PC, e.g. in Microsoft Excel[®], SAUTER AFI-1.0
- Data transfer software, KERN SCD-4.0
- Support rings for secure positioning, SAUTER AHMR 01
- Impact body Type D, net weight approx. 5,5 g, hardness ≥ 1600 HV, tungsten carbide, Impact ball Ø 3 mm, in accordance with the standard ASTM A956-02, SAUTER AHMO D01
- External impact sensor Type C. Low energy sensor: requires only 25 % impact energy compared to type D, for testing tiny or light objects or the surface of hardened layer, SAUTER AHMR C
- External impact sensor Type D, SAUTER AHMR D
- External impact sensor Type D+15. Slim front section for holes, grooves or re-entrant surfaces, SAUTER AHMR D+15
- External impact sensor Type DL, for very narrow surfaces (Ø 4,5 mm), SAUTER AHMR DL
- External impact sensor Type G. High energy sensor: 900 % impact energy compared to type D, SAUTER AHMR G
- Connection cable impact sensor SAUTER HMO-A04
- El Test block Type D/DC, Ø 90 mm (± 1 mm), net weight < 3 kg, hardness range
 790 ± 40 HL, SAUTER AHMO D02
 630 ± 40 HL, SAUTER AHMO D03
 530 ± 40 HL, SAUTER AHMO D04
- Factory calibration certificates for SAUTER AHMO D02, AHMO D03, AHMO D04, SAUTER 961-132

STANDARL)	OPTION							
	€ →	m	3				+	Ø	
MEMORY	USB	STATISTIC	UNIT	TOL	BATT	1 DAY	CAL BLOCK	SOFTWARE	+4

		HK-D				
Model	Sensor	Measuring range	Readout	Test block	Option Factory calibration certificates	
SAUTER		[Max] HL	[d] HL	Typ D/DC approx. 800 HL	KERN	
HK-D	Тур D	170-960	1	not standard	961-131	
HK-DB	Typ D	170-960	1	standard	961-131	



SAUTER CATALOGUE 2021

Pictograms



Adjusting program (CAL): For quick setting of the instrument's accuracy. External adjusting weight required



Calibration block: Standard for adjusting or correcting

the measuring device

Peak hold function: PEAK

Capturing a peak value within a measuring process



Scan mode: Continuous capture and display of measurements



tension and compression forces



Length measurement: Captures the geometric dimensions of a test



FOCUS

Focus function:

Increases the measuring accuracy of a device within a defined measuring range



Internal memory:

To save measurements in the device memory



Data interface RS-232:

Bidirectional, for connection of printer and PC



Profibus:

For transmitting data, e.g. between scales, measuring cells, controllers and peripheral devices over long distances. Suitable for safe, fast, fault-tolerant data transmission. Less susceptible to magnetic interference.



Profinet:

Enables efficient data exchange between decentralised peripheral devices (balances, measuring cells, measuring instruments etc.) and a control unit (controller). Especially advantageous when exchanging complex measured values, device, diagnostic and process information. Savings potential through shorter commissioning times and device integration possible



Data interface USB:

To connect the measuring instrument to a printer, PC or other peripheral devices

℅

Bluetooth* data interface: To transfer data from the balance/measuring

instrument to a printer, PC or other peripherals









ZERO: Resets the display to "0"

Battery operation:



Ready for battery operation. The battery type is

specified for each device



Rechargeable set

230 V



230V/50Hz in standard version for EU. On request GB, AUS or USA version available



Power supply:

Integrated, 230V/50Hz in EU. More standards e.g. GB, AUS or USA on request



Motorised drive: The mechanical movement is carried ELECTRO out by a electric motor



Motorised drive:

The mechanical movement is carried out by a synchronous motor (stepper)



Μ

Fast-Move:

The total length of travel can be covered by a single lever movement



Verification possible:

The time required for verification is specified +3 DAYS in the pictogram



DAkkS calibration possible:

The time required for DAkkS calibration is shown in days in the pictogram

ISO +4 DAYS

Factory calibration: The time required for factory calibration is specified in the pictogram



Package shipment: The time required for internal shipping

preparations is shown in days in the pictogram

Pallet shipment:



The time required for internal shipping preparations is shown in days in the pictogram

*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners.

Your KERN specialist dealer:



It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems

For connecting the scale/measuring instrument

GLP/ISO record keeping:

Of measurement data with date, time and PRINTER serial number. Only with SAUTER printers

WLAN data interface:

Data interface Infrared:

To connect relays, signal lamps,

To transfer data from the balance/measuring

instrument to a printer, PC or other peripherals

To transfer data from the measuring instrument

to a printer, PC or other peripheral devices

Control outputs (optocoupler, digital I/O):

To connect a suitable peripheral device for

analogue processing of the measurements

For output of an electrical signal depending

Using the saved values, the device

calculates statistical data, such as

To transfer the measurement data

to print out the measurement data

from the device to a PC

Network interface:

to an Ethernet network

average value, standard deviation etc.

A printer can be connected to the device

on the load (e.g. voltage 0 V - 10 V or current

Ì

WIFI

• (((() •

IR

_0_0_

SWITCH

ANALOG

ANALOG

Im

STATISTIC

SOFTWARE

古

LAN

KCP

PROTOCOL

valves, etc.

Analogue interface:

Analog output:

4 mA – 20 mA) Statistics:

PC Software:

Printer:

Measuring units:

Weighing units can be switched to e.g. non-metric at the touch of a key. Please refer to website for more details



Measuring with tolerance range

(limit-setting function): Upper and lower limiting can be programmed individually. The process is supported by an audible or visual signal, see the relevant model

S



