

Platform scale with stainless steel display device KERN IXS



Platform scale with stainless steel display device with IP68 rating, XL-display und EC type approval [M] – now also as high resolution version with high-resolution display



Piece-counting function



Durable stainless steel weighing plate



Stainless steel display device with IP68 protection, hygienic and easy to clean

## **KERN BALANCES & TEST SERVICES CATALOGUE 2021**

# KERN

#### Platform scale with stainless steel display device KERN IXS



#### Features

- Tough industry standard suitable for use in harsh industrial applications
- II Platform: weighing plate stainless steel, painted steel base, silicone-coated aluminium load cell, protection against dust and water splashes IP65, Substruction in wing design, extremely resistant to bending
- Superior display size: digit height 55 mm, bright backlight for easy reading of weighing results, even in poor lighting conditions
- Display device: Stainless steel, protection against dust and water splashes IP68, integrated power supply
- ESD drain to protect against electrostatic discharge e.g. for electrostatically-charged weighing objects or people who work with the scale
- Thanks to interfaces such as RS-232, RS-485 and Bluetooth (optional) the scale can easily be connected to existing networks and facilitates the data exchange between the scale and printer



#### **Technical data**

- Large backlit LCD display, digit height 55 mm
- Weighing plate dimensions, stainless steel  $$W{\times}D{\times}H$$
- A 300×240×86 mm
- 400×300×89 mm, see larger picture
- C 500×400×123 mm
- 650×500×133,5 mm
- Dimensions of display device W×D×H 232×150×80 mm
- Cable length of display device approx. 2,5 m
- Permissible ambient temperature -10 °C/40 °C

#### Accessories

Istand to elevate display device
Image: Image:

KERN IXS-A02

- II-II Height of stand approx. 400 mm, KERN IXS-A03
- ☑-☑ Height of stand approx. 600 mm, KERN IXS-A04



- Internal rechargeable battery pack, operating time up to 80 h without backlight, charging time approx. 12 h, KERN GAB-A04
- Data interface RS-232, interface cable included, approx. 1,5 m, must be ordered at purchase, KERN KXS-A04
- Data interface RS-485, must be ordered at purchase, KERN KXS-A01
- I Bluetooth data interface for wireless data transfer to PC or tablets, must be ordered at purchase, not in combination with verification, KERN KXS-A02
- Foot switch, must be ordered at purchase, KERN KXS-A03
- Roller conveyor attachment, with smooth-running, hot-dip galvanised steel rollers with ball bearings, robust aluminium profile frame, KERN YRO-01
- Further details, plenty of further accessories and suitable printers see *Accessories*



Model	Weighing	Readability	Verification	Minimal load	Net weight	Weighing			(	Option	
	range		value			plate		Verificat	ion	DAkkS Calibr. Ce	rtificate
	[Max]	[d]	[e]	[Min]	approx.			MU		DAkkS	
KERN	kg	g	g	g	kg			KERN		KERN	
IXS 6K-4	6	0,2	-	-	6	A		-		963-128	
IXS 10K-4	15	0,5	-	-	6	A		-		963-128	
IXS 10K-4L	15	0,5	-	-	11	В		-		963-128	
IXS 30K-3	30	1	-	-	11	В		-		963-128	
IXS 30K-3L	30	1	-	-	22	С		-		963-128	
IXS 60K-3	60	2	-	-	11	В		-		963-129	
IXS 60K-3L	60	2	-	-	22	С		-		963-129	
IXS 100K-3	150	5	-	-	22	С		-		963-129	
IXS 100K-3L	150	5	-	-	36	D		-		963-129	
IXS 300K-2	300	10	-	-	36	D		-		963-129	
	D	ual-range baland	ce switches auto	omatically to the	next largest w	eighing cap	bacity [Max] an	d readibility	[d]		
IXS 6K-3M	3   6	1   2	1   2	20   40	6	A		965-228		963-128	
IXS 10K-3M	6   15	2   5	2   5	40   100	6	A		965-228		963-128	
IXS 10K-3LM	6   15	2   5	2   5	40   100	11	В		965-228		963-128	
IXS 30K-2M	15   30	5   10	5   10	100   200	11	В		965-228		963-128	
IXS 30K-2LM	15   30	5   10	5   10	100   200	22	С		965-228		963-128	
IXS 60K-2M	30   60	10   20	10   20	200   400	11	В		965-229		963-129	
IXS 60K-2LM	30   60	10   20	10   20	200   400	22	С		965-229		963-129	
IXS 100K-2M	60   150	20   50	20   50	400   1000	22	С		965-229		963-129	
IXS 100K-2LM	60   150	20   50	20   50	400   1000	36	D		965-229		963-129	
IXS 300K-2M	150   300	50   100	50   100	1000   2000	36	D		965-229		963-129	
No	te: For applicati	ions that require Verific		ease order verific ory, we need to					date is n	ot possible.	

\* Either RS-232 or RS-485 can be installed and used

# **KERN BALANCES & TEST SERVICES CATALOGUE 2021**

KCP

PROTOCOL

GLP

INTERN

PRINTER

PCS

RECIPE

RECIPE

- 88'

SUM

PERCENT

C

UNIT

- → +<

TOL

^-

digital systems GLP/ISO log:

connection GLP/ISO log:

printers

**Piece counting:** 

Recipe level A:

Recipe level B:

**Totalising level A:** 

value (100 %)

Weighing units:

Hold function:

**KERN Communication Protocol (KCP):** 

It is a standardized interface command set for

KERN balances and other instruments, which

devices featuring KCP are thus easily integrated

with computers, industrial controllers and other

The balance displays serial number, user ID,

With weight, date and time. Only with KERN

Reference quantities selectable. Display can

The weights of the recipe ingredients can

be added together and the total weight of

Internal memory for complete recipes with

The weights of similar items can be added

Determining the deviation in % from the target

Can be switched to e.g. nonmetric units at the

(Checkweighing) Upper and lower limiting can

be programmed individually, e.g. for sorting and

dosing. The process is supported by an audible

(Animal weighing program) When the weighing

conditions are unstable, a stable weight is calculated as an average value

or visual signal, see the relevant model

touch of a key. See balance model. Please refer

together and the total can be printed out

name and target value of the recipe ingredients.

be switched from piece to weight

the recipe can be printed out

User guidance through display

Percentage determination:

to KERN's website for more details

Weighing with tolerance range:

weight, date and time, regardless of a printer

allows retrieving and controlling all relevant parameters and functions of the device. KERN



#### Pictograms



#### Internal adjusting: Quick setting up of the balance's accuracy with



### Adjusting program CAL:

For quick setting up of the balance's accuracy. External adjusting weight required

internal adjusting weight (motordriven)



Easy Touch: Suitable for the connection, data transmission and control through PC, tablet or smartphone.



### Memory:

Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.



Alibi memory:

Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard

#### Data interface RS-232:

• 6550.• To connect the balance to a printer, PC or RS 232 network



#### **RS-485 data interface:**

To connect the balance to a printer, PC or other peripherals. Suitable for data transfer over large distances. Network in bus topology is possible



#### USB data interface:

To connect the balance to a printer, PC or other peripherals

#### Bluetooth\* data interface:

To transfer data from the balance to a printer, PC or other peripherals



\*

#### WiFi data interface:

To transfer data from the balance to a printer, PC or other peripherals



Control outputs (optocoupler, digital I/O): To connect relays, signal lamps, valves, etc.



#### Analogue interface:

to connect a suitable peripheral device for analogue processing of the measurements



#### Interface for second balance:

For direct connection of a second balance



## Network interface:

For connecting the scale to an Ethernet network






water splashes IPxx: The type of protection is shown in the pictogram

Protection against dust and

\*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners

#### UNDER the balance

Ę.





#### Ready for battery operation. The battery type

Suspended weighing:



is specified for each device

Load support with hook on the underside of



#### Rechargeable battery pack: Rechargeable set

#### Universal mains adapter:

with universal input and optional input socket MULTI adapters for A) EU, CH, GB; B) EU, CH, GB, USA; C) EU, CH, GB, USA, AUS



#### Mains adapter:

230V/50Hz in standard version for EU, CH. On request GB, USA or AUS version available

#### Power supply:



Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request



#### Weighing principle: Strain gauges:

Electrical resistor on an elastic deforming body



#### Weighing principle: Tuning fork:

A resonating body is electromagnetically excited, causing it to oscillate



#### Weighing principle: Electromagnetic force compensation:

Coil inside a permanent magnet. For the most accurate weighings



# Weighing principle: Single cell technology:



#### Advanced version of the force compensation principle with the highest level of precision



#### The time required for verification is specified +3 DAYS in the pictogram

DAkkS calibration possible (DKD): DAkkS The time required for DAkkS calibration is +3 DAYS shown in days in the pictogram

# Factory calibration (ISO):



The time required for Factory calibration is shown in days in the pictogram



#### Package shipment:



The time required for internal shipping preparations is shown in days in the pictogram

#### Pallet shipment:



Your KERN specialist dealer:

The time required for internal shipping preparations is shown in days in the pictogram

#### **KERN – Precision is our business**

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAkkS calibration certificate the best pre-requisite for proper balance calibration.

The KERN DAkkS calibration laboratory today is one of the most modern and bestequipped DAkkS calibration laboratories for balances, test weights and force-measurement in Europe

Thanks to the high level of automation, we can carry out DAkkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

#### Range of services:

- · DAkkS calibration of balances with a maximum load of up to 50 t
- · DAkkS calibration of weights in the range of 1 mg 2500 kg · Volume determination and measuring of magnetic susceptibility (magnetic
- characteristics) for test weights · Database supported management of checking equipment and reminder service
- · Calibration of force-measuring devices
- · DAkkS calibration certificates in the following languages DE, EN, FR, IT, ES, NL, PL
- · Conformity evaluation and reverification of balances and test weights